





IG L AND Compact 3500/2 LH Parts Catalogue

Winch Head (for Fixed Mounting)

Serial No.: 0001 ⇨

This Parts Catalogue does NOT cover
3502 TL, 3502 A, 3502 AT, 3502 HT or 3502 T.



021510
Early version.
Not available.
See Parts Catalogue
Fixed Mounting, page 11

GENERAL INFO:


This Parts Catalogue supersedes Parts List Nos:
914-0, 922-0, 922-1, 935-0, 935-1, 935-2,
935-2 GS, 935-3, 935-3 GS, 1320-0, 1320-1.

This Parts Catalogue consists of 24 numbered pages.


This Catalogue: P/N 390306

© IG L AND AS

- Gjengivelse av tekst og tegnninger tillates forbudt.
- Reproduction of text or illustrations without permission is prohibited.
- Eine Wiedergabe von Texten und Zeichnungen ohne unsere Genehmigung ist nicht gestattet.
- Interdiction de toute reproduction de textes ou d'illustrations sans autorisation préalable.




If fitted
See page 16




See page 5



If fitted
See page 16



If fitted
See page 21




See page 2

Approved:



Revised: AIS 10.02.98

Issued: 21S/21 20.07.94






IGLAND Compact 3500/2 LH

"HEAD"



IGLAND Compact 3500/2 LH

"HEAD"



NBI For later version of housing: 132045
026037
NBI For early versions of housing: 131510/131519

010185

026331

031859

013341

012234

131526

(incl. inner 40 mm bearing)
See NOTE

131627

031859

131528

132033

023560

070369

070368

070378

Universal length

131513

131510

Early version. Not available. When exhausted, use P/N 132045

132019

Early version. Not available. When exhausted, use P/N 132045

024501

023560

132033

023560

132045

026037

NBI For later version of housing: 132045

NBI For early versions of housing: 131510/131519

026331

132033

023560

024501

132046

026331

031859

013341

012234

131526

(incl. inner 40 mm bearing)
See NOTE

131627

031859

131528

132033

023560

070369

070368

070378

Universal length

131513

131510

Early version. Not available. When exhausted, use P/N 132045

132019

Early version. Not available. When exhausted, use P/N 132045

024501

023560

132033

023560

132045

026037

NBI For later version of housing: 132045

NBI For early versions of housing: 131510/131519

026331

132033

023560

024501

132046

026331

031859

013341

012234

131526

(incl. inner 40 mm bearing)
See NOTE

131627

031859

131528

132033

023560

070369

070368

070378

Universal length

131513

131510

Early version. Not available. When exhausted, use P/N 132045

132019

Early version. Not available. When exhausted, use P/N 132045

024501

023560

132033

023560

132045

026037

NBI For later version of housing: 132045

NBI For early versions of housing: 131510/131519

026331

132033

023560

024501

132046

026331

031859

013341

012234

131526

(incl. inner 40 mm bearing)
See NOTE

131627

031859

131528

132033

023560

070369

070368

070378

Universal length

131513

131510

Early version. Not available. When exhausted, use P/N 132045

132019

Early version. Not available. When exhausted, use P/N 132045

024501

023560

132033

023560

132045

026037

NBI For later version of housing: 132045

NBI For early versions of housing: 131510/131519

026331

132033

023560

024501

132046

026331

031859

013341

012234

131526

(incl. inner 40 mm bearing)
See NOTE

131627

031859

131528

132033

023560

070369

070368

070378

Universal length

131513

131510

Early version. Not available. When exhausted, use P/N 132045

132019

Early version. Not available. When exhausted, use P/N 132045

024501

023560

132033

023560

132045

026037

NBI For later version of housing: 132045

NBI For early versions of housing: 131510/131519

026331

132033

023560

024501

132046

026331

031859

013341

012234

131526

(incl. inner 40 mm bearing)
See NOTE

131627

031859

131528

132033

023560

070369

070368

070378

Universal length

131513

131510

Early version. Not available. When exhausted, use P/N 132045

132019

Early version. Not available. When exhausted, use P/N 132045

024501

023560

132033

023560

132045

026037

NBI For later version of housing: 132045

NBI For early versions of housing: 131510/131519

026331

132033

023560

024501

132046

026331

031859

013341

012234

131526

(incl. inner 40 mm bearing)
See NOTE

131627

031859

131528

132033

023560

070369

070368

070378

Universal length

131513

131510

Early version. Not available. When exhausted, use P/N 132045

132019

Early version. Not available. When exhausted, use P/N 132045

024501

023560

132033

023560

132045

026037

NBI For later version of housing: 132045

NBI For early versions of housing: 131510/131519

026331

132033

023560

024501

132046

026331

031859

013341

012234

131526

(incl. inner 40 mm bearing)
See NOTE

131627

031859

131528

132033

023560

070369

070368

070378

Universal length

131513

131510

Early version. Not available. When exhausted, use P/N 132045

132019

Early version. Not available. When exhausted, use P/N 132045

024501

023560

132033

023560

132045

026037

NBI For later version of housing: 132045

NBI For early versions of housing: 131510/131519

026331

132033

023560

024501

132046


026331

031859


013341

IGLAND Compact 3500/2 LH

ELECTROHYDRAULIC LOW PRESSURE CONTROL "LH"




Current version



See page 6






Early version, for John Deere only.



See page 10

IGLAND Compact 3500/2 LH

ELECTROHYDRAULIC LOW PRESSURE CONTROL "LH"



If fitted
See page 7

See page 8

See page 8

See page 9

See page 10

See page 14

See page 15

IGLAND AS



Motstandsfri returkoblinger

Should be used by LH winches.

TRACTOR TYPE	P/N:	DIMENSION:
BELARUS	049421	1 1/4" R
CASE 585-885 XL, 495-995 XLT, 3200, 4200	049445	1 1/4" BSP
DEUTZ	049423	M26 x 1,5
FENDT 308	049422	M18 x 1,5
FIAT 60-94, 65-94, 72-94, 82-94, 88-94, from -94	049444	M22 x 1,5
FIAT (not 90/90 or 100/90)	049426	M22 x 1,5
FIAT 90/90 and 100/90	049425	M30 x 1,5
FORD 4130, 4630, 5030, 5640, 6640, 7740	049434	3/4" R
FORD 6410 and 6610, From A -89 mod.	049434	3/4" R
FORD -10 SERIE	049400	Eksp. 34 mm
INTERNATIONAL TYPE 1	049428	1 5/16" UNF
INTERNATIONAL TYPE 2	049429	1" UNF
INTERNATIONAL TYPE 3	049430	3/4" UNF
JOHN DEERE -40 serie	049438	1" - 11,5 NPT
JOHN DEERE -50 serie	049439	3/4" - 14 NPT
JOHN DEERE -3000 serie	049446	M24 x 1,5
JOHN DEERE -6000 serie	049440	M22 x 1,5
KUBOTA 345 L	049411	3/8" R
KOBOTA M7950 DT	049415	1" R
MB TRAC	049419	M30 x 1,5
MASSEY FERGUSON 250-265	049441	1 1/16" JIC
MASSEY FERGUSON 600 serien, from -84	049441	1 1/16" JIC
MASSEY FERGUSON 300 serien, from -87	049442	7/8" JIC
MASSEY FERGUSON 3000 serien, from -87	049443	1 1/16" JIC
VALMET 6100, 6300, 6400, 6600 MEZZO	049435	M30 x 2
VALMET 355, 455, 555, 465, 565, 665	049427	7/8" JIC
VALMET 305 - 405	049420	M30 x 2
VALMET 505 - 805	049412	
VALMET, Early model	049404	29 - 31 mm
ZETOR CRYSTAL 8145 - 4145	049433	M30 x 1,5
ZETOR 6520/40, 7520/40, 8520/40, 9520/40	049437	M48 x 1,5
ZETOR (all other models)	049414	
Universal type for oil supply	049404	29 - 31 mm
Universal type for oil supply	049400	34 - 36 mm
Universal type for oil supply	049405	37 - 39 mm
Universal type for oil supply	049402	49 - 51 mm



IGLAND Compact 3500/2 LH

ELECTROHYDRAULIC LOW PRESSURE CONTROL "LH"



IGLAND Compact 3500/2 LH



ELECTROHYDRAULIC LOW PRESSURE CONTROL "LH"



NOTE: Requires special skill on re-installation. If available, see Service Manual.

IGLAND Compact 3500/2 LH

ELECTROHYDRAULIC LOW PRESSURE CONTROL "LH"




A schematic diagram of a battery pack assembly. It features a central battery pack with several terminals. Various cables are connected to these terminals: a thick black cable with a rectangular connector, a thin black cable with a circular connector, a cable with a multi-pin connector, and a cable with a circular connector. The diagram is enclosed in a rectangular frame.

See page 6


See page 8

See page 12

Early version on
⇒ Jun. 87





↓ Jun. 85



IGLAND Compact 3500/2 LH

ELECTROHYDRAULIC LOW PRESSURE CONTROL "LH"





For "closed centre, early version"
Jun.85 → Jun.87



IGLAND Compact 3500/2 LH

ELECTROHYDRAULIC CONTROL


Electrical components



IGLAND Compact 3500/2 LH



ELECTROHYDRAULIC CONTROL

Electrical components




090760 Standard


090824 "GS"-versions only.



IGLAND Compact 3500/2 LH REMOTE CONTROL




Current versions:




Early models:

Infrared remote control




See page 18

Infrared remote control




See page 17

Radio remote control



See page 19

Radio remote control





See page 20




IGLAND Compact 3500/2 LH

INFRARED REMOTE CONTROL KIT.

Early version





(Transmitter, Receiver and Charger Unit)
If fitted.



RADIO REMOTE CONTROL KIT

EARLY VERSION,

Sesam/Ettestad Frequency: 30.035 MHz.





IGLAND Compact 3500/2 LH

RADIO REMOTE CONTROL KIT: 091130


(Transmitter and Receiver) Frequency: 40.685 MHz.

"GS" Version, (frequency: 433,2 MHz): 091139

If fitted.




IGLAND Compact 3500/2 LH




RADIO REMOTE CONTROL KIT, T-100, 4 ch.: 091160
RADIO REMOTE CONTROL KIT, T-150, 4 ch.: 091180
RADIO REMOTE CONTROL KIT, T-150, 6 ch.: 091181
RADIO REMOTE CONTROL KIT, T-150, 8 ch.: 091182

If fitted.
Add. price for extra 2 ch. transmitter/6 ch. receiver (only for 091160)
Add. price for frequency for Germany, Austria, Switzerland
Add. price for frequency for Great Britain

- 091161
- 091162
- 091163



Note 1: Frequency for Germany, Austria, Switzerland and
Note 2: Frequency for Great Britain




IGLAND Compact 3500/2 LH

RPM ACTUATOR, compl.: 091440
On/off function


RPM ACTUATOR, compl.: 091441
Stepless function.

If fitted.

Early version





Current version



IGLAND Compact 3500/2 LH







Miscellaneous



WIRE ROPE, 6x26WS+IWRC 180 kp, 10 mm



WIRE ROPE, according to ISO 4254-4



Intentionally blank